

Changing to the New Frequency on a Baofeng Radio

On the Baofeng Radio you will change the frequency using either Channel A or B.

Push the orange VFO/MR button to select the Frequency Mode.

Push the blue A/B button to select either channel A or B.

Use the keypad to type in the frequency 462550

Press the # key in the lower right corner to select the LOW (@ 1 watt) power level.

Each time you press the # key it will toggle between HIGH, MEDIUM, and LOW power levels and you will see a H,M, or L indicator on the screen. Use the LOW setting.

